



Congratulations on your purchase of your Cruiser Caddie. This is a guide for you initial assembly and setup.

This is a list of items you should have received:

- Truck section
- Ramp section
- Six pipe supports
- Wheel chock / Carriage with support bar
- Winch
- Mini ramp
- Two hold down bars
- Two Ratchet straps
- Two hold down straps
- Two soft straps

1) Bolt winch onto the truck section.

- 2) Screw pipe supports into truck section.
- 3) Slide truck section into truck.
- 4) Set and install hold down bars. See fig 1



**Figure 1**

- 5) Bolt support bar onto wheel chock/carriage making sure ears are pointing towards rear of carriage See fig 2



**Figure 2**

- 6) Slide carriage into end of truck section.
- 7) Screw pipe supports into bottom end of ramp section.
- 8) Lock ramp section into truck section. See fig 3



**Figure 3**

9) Strap top of ramp section to bumper or trailer hitch. See fig. 4



**Figure 4**

10) Connect winch to carriage. See fig 5



**Figure 5**

11) Connect winch to battery (red to + )

12) Lower carriage to bottom of ramp section. Note: whenever you are lowering

carriage there must be a downward tension on the cable .

### **13) Insert carriage locking pins. See fig 6**



**Figure 6**

14) Place mini ramp onto back of carriage. See fig 7



**Figure 7**

15) Load bike into carriage. ( the tire shoe in the carriage is adjustable. The present setting is correct for most tire sizes ) See fig 8



**Figure 8**

- 16) Attach ratchet straps from bike to carriage support bar. Straps should be attached on the lower forks ( ( recommended method) (see fig 9)). Straps can be attached to handle bars (see fig 10) but compression of forks will leave less clearance under frame.



**Figure 9**



**Figure 10**

Adjust straps so bike is in a straight and upright position.

- 17) Remove mini ramp.
- 18) Remove carriage locking pins.
- 19) Using winch remote control pull bike onto truck.
- 20) Remove straps from top of ramp section.
- 21) Slide ramp section into truck and secure.
- 22) Secure bike to truck.
- 23) To unload simply reverse process.

Note : when unloading bike you must assert pressure back on bike while holding the out button on the winch remote until back wheel of bike is on the down section of the ramp.

If you have any questions feel free to contact us.

Phone 610-323-9439

Thank you and enjoy your ride.